


DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests



Alex CUPPENS, Jasper VISTE, Jiabin LI, Tomohiro SUZUKI,

KU Leuven, Belgium

Georgios FOURTAKAS,

The University of Manchester, United Kingdom

DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests

Two major problems in the construction industry for a sustainable society




1. Cement: 8% of global CO₂ emission



2. Construction & Demolition Waste (CDW):
40% of all solid waste

DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests



- **Geopolymers:** Sustainable, low-carbon binders
- **Made from** industrial by-products or/and recycled materials
- **Using Geopoylmer binders** → up to 80% decrease in CO₂

DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests




Slump Test



Useful to quickly assess workability and placement feasibility on site


DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests




Mini Slump Test

can be regarded as a *laboratory-scale alternative* to the slump test.

Pashias et al. (1996)




Side view



'bottom' view

- Requires only small material volumes
- Highly sensitive to paste rheology (reliability is high)
- Provides time-dependent flow information


DualSPHysics Modelling of CDW-based Geopolymer Paste Flow in Mini Slump Tests




Mini Slump Test

can be regarded as a *laboratory-scale alternative* to the slump test.

Pashias et al. (1996)



Side view



‘bottom’ view

- Requires only small material volumes
- Highly sensitive to paste rheology (reliability is high)
- Provides time-dependent flow information

DualSPHysics can be applied

Research Methodology

1. Materials: GGBS + RCP, as a Geopolymer Paste

2. Experimental:


- Rotational Rheometer (input fundamental properties)
- Mini Slump Test (on-site Quality Control)

3. Numerical:

- DualSPHysics v5.0

4. Analysis:

- Compare DualSPHysics with Mini Slump Test



Mix Design Strategy

Constants:

- Solid Precursor: 60% GGBS + 40% RCP
- $\text{Na}_2\text{O}/\text{b}$: 8 %

	SiO ₂ / Na ₂ O = 1,20->1,70 met w/b = 0,4						
	G-8%-1,20-0,4	G-8%-1,30-0,4	G-8%-1,33-0,4	G-8%-1,40-0,4	G-8%-1,50-0,4	G-8%-1,60-0,4	G-8%-1,70-0,4
Binder [g]	100	100	100	100	100	100	100
GGBS [%]	60	60	60	60	60	60	60
RCP [%]	40	40	40	40	40	40	40
SiO ₂ / Na ₂ O [%]	1,2	1,3	1,33	1,4	1,5	1,6	1,7
Na ₂ O/b [%]	0,08	0,08	0,08	0,08	0,08	0,08	0,08
w/b [%]	0,4	0,4	0,4	0,4	0,4	0,4	0,4
Na ₂ SiO ₃ [g]	35,9	38,9	39,8	41,9	44,9	47,9	50,9
NaOH [g]	6,7	6,4	6,3	6,1	5,7	5,4	5,1
H ₂ O [g]	16,2	14,2	13,6	12,2	10,3	8,3	6,3
Activator [g]	58,8	59,5	59,7	60,2	60,9	61,6	62,3


Series 1: Varied the SiO₂/Na₂O ratio while keeping the water-to-binder (w/b) ratio constant at 0,40.

	w/b = 0,30 -> 0,60 met SiO ₂ /Na ₂ O = 1,33						
	G-8%-1,33-0,30	G-8%-1,33-0,35	G-8%-1,33-0,40	G-8%-1,33-0,45	G-8%-1,33-0,50	G-8%-1,33-0,55	G-8%-1,33-0,60
Binder [g]	100	100	100	100	100	100	100
GGBS [%]	60	60	60	60	60	60	60
RCP [%]	40	40	40	40	40	40	40
SiO ₂ / Na ₂ O [%]	1,33	1,33	1,33	1,33	1,33	1,33	1,33
Na ₂ O/b [%]	0,08	0,08	0,08	0,08	0,08	0,08	0,08
w/b [%]	0,3	0,35	0,4	0,45	0,5	0,55	0,6
Na ₂ SiO ₃ [g]	39,8	39,8	39,8	39,8	39,8	39,8	39,8
NaOH [g]	6,3	6,3	6,3	6,3	6,3	6,3	6,3
H ₂ O [g]	3,6	8,6	13,6	18,6	23,6	28,6	33,6
Activator [g]	49,7	54,7	59,7	64,7	69,7	74,7	79,7

Series 2: Varied the water-to-binder (w/b) ratio while keeping the SiO₂/Na₂O ratio constant at 1,33.

How do the Rheological Properties Change??

The Automated Mini Slump Test




Custom-built, automated apparatus:

- **Advantage:**

- Cost-effective
- Ensures a consistent, repeatable test


- **Components:**

- VEVOR Linear Actuator (controlled lift)
- DC Power Supply
- Adjustable legs
- Transparent Acrylic Table
- Video recording




Mini Slump Test Procedure & Data


Lift at 10 mm/s




View from bottom



Digitize diameter in time




Experimental Results: Mini Slump Test



Conclusion: The mini slump test is a highly sensitive and reliable tool that can be used for on-site quality control.


Numerical Approach with SPH

$$F(\mathbf{r}) \approx \sum_{j=1}^N F(\mathbf{r}_j) W(\mathbf{r}-\mathbf{r}_j, h) \frac{m_j}{\rho_j} = \sum_{j=1}^N F(\mathbf{r}_j) W(\mathbf{r}-\mathbf{r}_j, h) V_j$$





rheometer data (τ_y and μ_p) as inputs to the SPH simulation
 => to see if it replicates mini-slump test results.

SPH Simulation Setup



$$\vec{\tau} = \eta_{app} \cdot \vec{\dot{\gamma}}$$
$$\eta_{app} = \mu |\vec{\dot{\gamma}}|^{n-1} + \frac{\tau_y}{|\vec{\dot{\gamma}}|} \left[1 - e^{-m|\vec{\dot{\gamma}}|} \right]$$



Geometry: The cone lift and the dimensions



Model: Herhsel-Bulkley-Papanastasiou modified Bingham fluid $m=100$, $n=1$

Parameters: a 'standard' set of SPH parameters (personal communication with Foutakas, 2025)



Inputs: τ_y and μ_p from my rheometer tests

Simulation and post-processing with 'Tracker'


Simulation



Tracker



SPH Results



Calibration Mix: w/b = 0.55

Parameters:

- dp = 1,2 mm or 0,6 mm
- m = papanastasiou regularization parameter = 100, 600, 1000, 1200
- Velocity Gradient type = FDA or SPH
- Viscosity Treatment = Artificial, Laminar+SPS, Constitutive
- Density Diffusion Term = Molteni, Fourtakas (full)
- Density Diffusion Term Value = 0,01; 0,03; 0,05; 0,1
- Slipmode = (DBC vel=0) or No-Slip

Constitutive, Molteni


Summary:

Simulations over-predicted spreading rate & final diameter
No calibration


Limitation 1

- **Boundary condition:**
 - **DBC:** Simple & stable, but creates a gap → inaccurate boundary pressures
 - **mDBC:** Ghost nodes + interpolation → closes the gap, improves accuracy at walls & corners
- **Issue:** mDBC is not yet supported for non-Newtonian solver in DualSPHysics v5.0

Sloshing Tank



small unphysical gap ($\approx$ the smoothing length h)



Limitation 2

- Wall friction model
- **issue: Viscoboundfactor** cannot be activated with a correct non-Newtonian constitutive model or Laminar+SPS model

XML file

EXECUTION-PARAMETERS

Viscosity treatment

```
<parameter key="ViscoTreatment" value="1"
comment="Viscosity formulation 1:Artificial, 2:Laminar+SPS (default=1)" />
<parameter key="Visco" value="0.02" comment="Viscosity value" />
<parameter key="ViscoBoundFactor" value="1"
comment="Multiply viscosity value with boundary (default=1)" />
```

$$\frac{d\mathbf{v}_a}{dt} = -\sum_b m_b \left(\frac{P_b + P_a}{\rho_b \cdot \rho_a} + \Pi_{ab} \right) \nabla_a W_{ab} + \mathbf{g}$$

$$\Pi_{ab} = \begin{cases} \frac{-\alpha \overline{c_{ab} \mu_{ab}}}{\rho_{ab}} & \mathbf{v}_{ab} \cdot \mathbf{r}_{ab} < 0 \\ 0 & \mathbf{v}_{ab} \cdot \mathbf{r}_{ab} > 0 \end{cases}$$

α_{ff} for interaction fluid-fluid

α_{fb} for interaction fluid-boundary

$\alpha_{fb} = \text{ViscoBoundFactor} \cdot \alpha_{ff}$

Conclusion

- **Experiments for validation**
- **DualSPHysics v5.0 is applied to the Mini Slump Test**
- **Overestimation of the spreading rate & final diameter**
- **Detected some potential improvement points**

Thanks for your kind attention!

Future Prospects

Phase 1: Addressing Software Deficiencies

Action 1: Implement & validate wall-friction model for non-Newtonian fluids

Action 2: Make mDBC fully compatible with non-Newtonian solver

Expected Result:

Physically capable tool for boundary-dominated viscoplastic flows

Phase 2: Build Predictive model

Action: Large parametric study → hundreds of SPH runs (vary τ_y and μ_p)

Action: Record full diameter–time curves

Expected Result: Database linking rheology ↔ flow behaviour

Phase 3: Derive final mathematical model

Action: Use SPH database → equations linking $D(t)$ to τ_y & μ_p

Model Form: Generalized, tailored to CDW-based geopolymers

Expected Result: Validated framework converting field mini slump data → rheological properties

$$D = \alpha + 29.8 \ln(t + \gamma) - \lambda \left(\frac{t^{0.842}}{13.5 + t^{0.842}} \right)$$

